





HANGING INSTRUCTIONS – Mini Quilt Wall Hanger

COMMITMENT TO EXCELLENCE

We want you to be pleased with our products and service, so if you need assistance, have any suggestions, or are not pleased with your purchase, please contact us in any way listed below:

Phone (937) 506-0032
E-mail info@quiltdisplayproducts.com
Website www.quiltdisplayproducts.com

Step 1 – Marking the location	Step 2 – Installing the anchor
<p>Mark a location on the wall at height "H" from the ceiling where you want to mount your mini wall hanger.</p>  <p>The diagram shows a horizontal line labeled 'Ceiling'. A vertical line with arrows at both ends is labeled 'H', indicating the height from the ceiling to the mark. Below this, a brown rectangular piece labeled 'Back of Mini Wall Hanger' is shown with a red 'X' mark on its surface, labeled 'Mark'.</p>	<p>Use a Phillips screwdriver to insert an E-Z Ancor™ at the marked location on the wall. Be sure after tightening, that the surface of the E-Z Ancor™ is flush with the wall.</p>  <p>The image shows a silver metal E-Z Ancor anchor and a black Phillips screwdriver.</p> <p>The E-Z Ancor™ is designed to be installed into drywall, or drywall backed by a wooden stud. If this doesn't work for you, remove the E-Z Ancor™ and drill a 1/8" hole into the stud, and then reinsert the E-Z Ancor™.</p>
Step 3 – Installing the wooden support	Step 4 – Attaching and hanging your quilt
<p>Use the screw provided to attach the wooden support to the E-Z Ancor™.</p> <p>Position the support such that the sharp edge is pointing toward the ceiling and away from the wall.</p> <p>Be sure the sharp edge is parallel with the ceiling when tightening the screw.</p>  <p>The diagram shows an E-Z Ancor anchor, a wooden support block with a hole and a sharp edge, and a screw. Labels include 'E-Z Ancor™', 'Sharp Edge', 'Wooden Support', and 'Screw'.</p>	<p>To hang your quilt, use a Phillips screwdriver to separate the mini wall hanger front and back halves. Center the binding of your quilt in the groove and then align the back, reinsert the screws and tighten.</p>  <p>The diagram shows the front and back halves of the Mini Wall Hanger. The front half has a groove and a binding. The back half has a sharp edge. A blue quilt is shown hanging from the front half. Labels include 'Screw', 'Binding', 'Groove', 'Front of Mini-Hanger', 'Back of Mini-Hanger', and 'Back of Quilt'.</p> <p>Place the mini quilt wall hanger on the wooden support you attached to your wall. You can slide your mini wall hanger left or right about 1/4 inch which is a nice feature if you are trying to line up more than one hanger in a vertical fashion.</p> <p>If your mini wall hanger appears crooked on the wall, simply loosed the support, reposition it and tighten it again as described in Step 3.</p>